

# T1 TIMER INSTRUCTIONS

## 1. SET DESIRED TIME

- Choose minutes or seconds using blue jumper. (jumper on the pins is minutes, off the pins is seconds).
- Adjust rotary knobs to desired time: left knob represents 10's, right knob the single minutes. Time is adjustable from 0-99 seconds or 0-99 minutes.




SECONDS



MINUTES

## 2. CHOOSE MODE

By adjusting the slide switches, the timer is capable of 2 modes: manual shutoff (mode 1) or automatic shutoff. (mode 2)



## 3. INSERT BATTERY

Snap the battery into the harness and insert it into the battery holder as shown.

## 4. OPERATION

- Push the button to start the timing cycle.
- The buzzer will chirp once and LED will flash throughout the cycle to let you know it is timing.
- When the time has elapsed, the audio alarm activates and the LED blinks slowly. Push the button again to silence the alarm in mode 1. If in mode 2, the timer will stop alarming by itself after 2 seconds.
- Timing cycle can be cancelled by pushing the button during the cycle. Timer will chirp to let you know it has been cancelled.

Sep 2, 2015